

Fig. 1A




Data "0"

Fig. 1B




Data "1"



SS 340 120 NOR 320 NG0 NG-1 F0n-2 F0n-1 F0n-3 F00 F02 F01 Fig. 3A Fuse Box FBn-3 Fuse Box FBn-2 Fuse Box FBn-1 Fuse Box FB0 Fuse Box FB2 Fuse Box FB1 300 CLKB | Address AX0-AX(n-1)

Fig. 3B

<u>FBi</u>



CS2 180 Vcc 500 MUX2 Vgnd ~ 220 780 7160 Fig. 4 Cell Array Data Output Cell Selecting Section Dout MUX1 SA 100 SS 120 Repair Control

Fig. 5

